


Day running lights

(some markets)




- A Fusebox
- B Ignition switch
- C Bulb failure warning sensor
- D Light switch
- E Day running lights and parking lights
- F Connector
- G Connector

Fuse No. 5
No other functions


Fuse No. 15
Numberplate light

Fuse No. 16
Lighting, instruments and controls

Ignition ON
Day running lights ON



Ignition OFF, parking lights ON.
Parking lights grounded via day running lights



Day running lights

(some markets)

